

MOTOR & CIRCUIT PROTECTION

Thermal overload relays for BF series contactors



Phase failure sensitive



RF38...

Order code	Adjustment range	Protection fuses		Qty per pkg	Wt [kg]
		aM [A]	gG [A]		

MANUAL OR AUTOMATIC RESETTING.
Direct mounting on BF09 - BF38 contactors.
Independent mounting with RFX38 04 base.

RF38 0016	0.1-0.16	0.25	—	1	0.140
RF38 0025	0.16-0.25	0.5	—	1	0.140
RF38 0040	0.25-0.4	0.5	1	1	0.140
RF38 0063	0.4-0.63	1	2	1	0.140
RF38 0100	0.63-1	2	4	5	0.140
RF38 0160	1-1.6	2	4	5	0.140
RF38 0250	1.6-2.5	4	6	5	0.140
RF38 0400	2.5-4	4	6	5	0.140
RF38 0650	4-6.5	8	16	5	0.140
RF38 1000	6.3-10	10	20	5	0.140
RF38 1400	9-14	16	32	5	0.140
RF38 1800	13-18	25	40	5	0.140
RF38 2300	17-23	25	50	5	0.140
RF38 2500	20-25	32	50	5	0.140
RF38 3200	24-32	40	63	1	0.140
RF38 3800	32-38	45	63	1	0.140

MANUAL RESETTING.
Direct mounting on BF50-BF110 contactors.
Complete with G261 links.
Independent mounting with G270 base.

11 RF95 3 33	20 - 33	40	63	1	0.348
11 RF95 3 42	28 - 42	45	80	1	0.348
11 RF95 3 50	35 - 50	50	100	1	0.348
11 RF95 3 65	46 - 65	80	125	1	0.348
11 RF95 3 82	60 - 82	100	200	1	0.348
11 RF95 3 95	70 - 95	100	200	1	0.348
11 RF95 3 110	90 - 110	125	200	1	0.348

AUTOMATIC RESETTING.
Direct mounting on BF50-BF110 contactors.
Complete with G261 links.
Independent mounting with G270 base.

11 RFA95 3 33	20 - 33	40	63	1	0.348
11 RFA95 3 42	28 - 42	45	80	1	0.348
11 RFA95 3 50	35 - 50	50	100	1	0.348
11 RFA95 3 65	46 - 65	80	125	1	0.348
11 RFA95 3 82	60 - 82	100	200	1	0.348
11 RFA95 3 95	70 - 95	100	200	1	0.348
11 RFA95 3 110	90 - 110	125	200	1	0.348



11 RF95 3...



11 RFA95 3...

Three-phase motor powers ①

230V [kW]	400V [kW]	415V [kW]	440V [kW]	500V [kW]	690V [kW]
-----------	-----------	-----------	-----------	-----------	-----------

②	②	②	②	②	0.06
②	0.06	0.06	0.06-0.09	0.06-0.09	0.09-0.12
0.06	0.09	0.09	0.12	0.12	0.18
0.09	0.12-0.18	0.12-0.18	0.18	0.18	0.25
0.12	0.25	0.25	0.37	0.25-0.37	0.37-0.55
0.18-0.25	0.37-0.55	0.37-0.55	0.55	0.55-0.75	0.75
0.37	0.75	0.75	0.75-1.1	1.1	1.1-1.5
0.55-0.75	1.1-1.5	1.1-1.5	1.1	1.5-2.2	2.2-3
1.1-1.5	2.2	2.2	2.2-3	3	4
1.5-2.2	3-4	4	4	4-5.5	5.5-7.5
3	5.5	5.5	5.5-7.5	5.5-7.5	11
4	7.5	7.5-9	9	11	15
5.5	11	9-11	11	11	18.5
5.5	11	11	11	15	22
7.5	15	15	15	18.5	30
11	18.5	18.5	18.5	22	30

7.5	11-15	11-15	15-18.5	15-18.5	22-25
9-10	15-18.5	18.5-22	18.5-22	22-25	30-33
10-11	22	25	25	30	37-40
15-18.5	25-30	30-33	30-33	33-40	45-55
22	33-40	37-45	37-45	45-55	59-75
22-25	40-45	45-51	45-55	55-63	75-80
30	55	55	55	75	90

7.5	11-15	11-15	15-18.5	15-18.5	22-25
9-10	15-18.5	18.5-22	18.5-22	22-25	30-33
10-11	22	25	25	30	37-40
15-18.5	25-30	30-33	30-33	33-40	45-55
22	33-40	37-45	37-45	45-55	59-75
22-25	40-45	45-51	45-55	55-63	75-80
30	55	55	55	75	90

- ① The indicated powers apply to 4-pole motors; it is advisable to always check that the nameplate motor current is within the relay adjustment range.
② No standard powers ratings exist; select relay according to current consumption.

Certifications and compliance

Certifications obtained:

Type	c U L u s	C S A	G O S T	C C C	Registers of shipping	
					R I N A	L R O S
RF38	●	—	●	●	▲	▲
RF95	●	●	●	●	●	●
RFA95	●	●	●	●	—	—

- Certified products.
▲ Pending completion.

Compliant with standards: IEC/EN 60947-1, IEC/EN 60947-4-1, UL508, CSA C22.2 n° 14.